

PR 720/30 Low Temperature Moulding Grade High Consistency Silicone Rubber (HCR)

Characteristics

Vulcanised articles manufactured from PR720/30 low temperature moulding grade silicone rubber exhibit a unique combination of characteristics and properties. They are noted for their good damping properties and very low temperature resistance. PR720/30 can be pigmented.

Product Data Safety Information

Material Reference: PR 720 / 30 (HCR Moulding Grade)

Special Features: • Temperature range from -110 °C to 250 °C

· Good damping coefficient

Low resilience

Wide service temperature range

Very low temperature flexibility

Colour: Translucent

Detailed, safety specific information can be obtained from the Material Safety Data Sheets

(MSDS), which are available upon request.

Physical Properties

| Test | Standard | Units | Typical Values |
|--------------------|--------------|---------|----------------|
| Hardness | ISO 7619-1 | Shore A | 30 |
| Density | ISO 2781 | g/cm³ | 1.10 |
| Tensile Strength | ISO 37 | MPa | 9.4 |
| Elongation @ Break | ISO 37 | % | 715 |
| Tear Strength | ASTM D 624 B | kN/m | 26 |

Typical Cure Conditions

| Press-Cure | 10 minutes @ 165 °C | |
|---------------|---|--|
| Post-Cure | 4 hrs @ 200 °C (in ventilated air) | |
| Catalyst Type | Dicumyl Peroxide (98%) or, 45 % paste of 2,5-bis-(t-butylperoxy)-2,5-dimethyl-hexane in silicone rubber | |

This data is obtained from test pieces moulded in the laboratory and are intended as a guide. They should not be used in preparing specifications.



Quality Assurance

Production Conditions

Sterilizing Conditions

All Primasil Silicone Rubber products are manufactured in accordance to the Quality Management Systems of ISO 9001 and if required; ISO 13485 and TS 16949. Full documentation and full traceability are ensured.

At Primasil Silicones, controls are implemented to ensure critical parameters are monitored throughout the entire production process to achieve customer requirements.

It is the user's responsibility to validate a sterilisation process for silicone mouldings / products. The user should conduct testing if sterilisation conditions vary and/or if minor property changes could affect performance. Common sterilisation procedures include:

- 1. Autoclave (Steam-sterilisation). Silicone mouldings can be effectively sterilised by steam in an autoclave. However, silicone materials are more difficult to heat than other materials, such as thermoplastics, because they have thermal insulating properties and so care must be taken to ensure properties are not altered.
- 2. Gamma Radiation Sterilisation. Gamma radiation studies of the effects on the physical properties of the silicone elastomer have shown that doses of radiation up to 2.5 Mrad (25kGy) do not adversely affect hardness, elongation, modulus, tensile or tear strength. Repeated gamma sterilisation processing at higher doses and for longer periods however, may affect some of the physical properties of the elastomer. Testing should therefore be conducted by the user if sterilisation conditions vary and if minor property could affect application changes performance.
- **3. Ethylene Oxide Sterilisation (ETO).** ETO has been used to sterilise silicone products with no degradation of physical properties. Sterilisation by this method is only recommended if procedures allow sufficient time for complete out-gassing of residual ETO and ETO by-products.